









DALI OPTICON MK2







QUICK START GUIDE

1. Pack Contents

								
OPTICON 6 MK2	x1	x4	x4	x4	x4	x1	x1	x1
OPTICON 8 MK2	x1	x4	x4	x4	x4	x1	x1	x1


						
OPTICON 1 MK2	x2	x8	x8	x2	x1	
OPTICON 2 MK2	x1	x4			x1	
OPTICON LCR MK2	x1	x4			x1	x1
OPTICON VOKAL MK2	x1	x4			x1	

2. Position




www.dali-speakers.com/quickstartguides


3. Mounting (stand/shelf)





3. Mounting (floor)



3. Mounting (wall)



4. Wiring



OPTICON MK2

